Wall mounted DMX512 Master






Feature

- 1 zone
 Touch sensitive
- Glass interface(White & Black)
- · Save color and mode function


FC (F ØROHS (Warranty) () 2 ()


ameter			
Part No.	luput Voltage	Output	Size
SR-2811DMX	12-24VDC	DMX512 Signal	86x86x29.1

Product Size



Installation





- Play&pause button. There is only 1 build-in mode. When you touch this button, it will run.

Brightness Speed down Speed up

Sulton can save the color from mode or save color when you touch color wheel.

In "S" button, it saved "R/G/B" 3 colors in default. But with your operation, you can save another 3 colors replace those R/G/B colors.

When you press this button, 1 build-in mode will run, if now you see a favorite mode, then you can press "S" button for 5 seconds until connected lighting flashes. Then it saved successfully.

When you touch color wheel, if you touch a favorite color on it, then you want to save it, then you press "S" button for 5 seconds until the connected lighting flashes. Then it saved successfully.

- For Warm white, Natural white, Cool white changing. (Through the three RGB color mixing)
- Touching wheels Switch off and on, long press means default setting

R G B W Short press means switch on and off for each channel. 1st Long press means brightness+, 2nd Long press means brightness—.

At the corner of the panel there is a signal light, Blue means on, Red means off

3.2 Set the address: One 2811DMX has 40 addresses, 001 005 009 013......037. 001=1.2.3.4=RGBW 005=5.6,7.8=RGBW 009=9,10,11,12=RGBW

Safety & Warnings

- 1) The product shall be installed and serviced by a qualified person.
- 2) IP20.Please avoid the sun and rain. When installed outdoors, please ensure it is mounted in a water proof enclosure.
- 3) Always be sure to mount this unit in an area with proper ventilation to avoid overheating.
- 4) Please check if the output voltage of any LED power supplies used comply with the working voltage of the product.
- 5) Never connect any cables while power is on and always assure correct connections to avoid short circuits before switching on.
- 6) Please ensure that the cable is secured tightly in the connector
- 7) For update information please consult your supplier.

Warranty Agreement

- 1) We provide lifelong technical assistance with this product:
- ullet 3-year warranty. We print date on every products, for example :1125 means year 2011, week 25. The warranty is for free repair or replacement and covers manufacturing faults only.
- For faults beyond the 3-year warranty we reserve the right to charge for time and parts.
- 2) Limited Warrenty
- Any defects caused by wrong operation.
- \bullet Any damages caused by unauthorized removal, maintenance, modifying, incorrect connection and replacement of chips.
- Any damages due to transportation, vibration etc. after purchase.
- Any damages caused by earthquake, fire, lightning, pollution and abnormal voltage.
- Any damages caused by negligence, inappropriate storing at high temperatures and humidity or near harmful chemicals.
- Product has been updated
- 3) Repair or replacement as provided under this warranty is the exclusive remedy to the customer.